



DIRECT+
Conditioning System

ENVOY

AUTHORITY22

Pattern Information		Pattern Parameters		Supplies Information	
Date		Pattern Number		Lane Cleaner	Brunswick MAX10
Pattern Type	Recreational	Pattern Name	ENVOY HOUSE	Cleaner Mixture Ratio	10 : 1
Pattern Difficulty	Low	Mode	Clean & Oil	Cleaner Transition Distance	42 Authority22
Pattern Designer	Brunswick	Forward Speed	Quick Clean	Cleaner Spray End Distance	53 Envoy
Pattern Volume (ml)	17.61	Start Cleaner Spray	0	Lane Conditioner	Brunswick Connect
Surface Information		Start Squeegee	0	Notes Envoy Default Pattern	
Surface Type	Synthetic	Start Oiling	6		
Surface Brand	Brunswick Pro Lane	Split Pattern	No		
Age					

		Zone 1	Zone 2	Zone 3	Zone 4	Zone 5	Zone 6	Zone 7	Zone 8
Zone End Distance		10	18	30	40				
Zone Ratio	L	4.0 : 1	5.8 : 1	7.4 : 1	### : 1	### : 1	### : 1	### : 1	### : 1
	R	4.0 : 1	5.8 : 1	7.4 : 1	### : 1	### : 1	### : 1	### : 1	### : 1
Zone Volume (ml)		9.06	4.53	4.02	0.00	0.00	0.00	0.00	0.00

ZONE	7 Pin Side										Board Number										10 Pin Side																		
	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1
1	18	18	18	18	18	19	25	45	65	77	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	77	65	45	25	19	18	18	18	18
2	10	10	10	10	10	10	10	11	15	34	53	58	58	58	58	58	58	58	58	58	58	58	58	58	58	58	58	58	53	34	15	11	10	10	10	10	10	10	10
3	5	5	5	5	5	5	6	7	8	29	37	37	37	37	37	37	37	37	37	37	37	37	37	37	37	37	37	37	29	8	7	6	5	5	5	5	5	5	5
4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
5																																							
6																																							
7																																							
8																																							

